

WirelessProfessional

Setup and Operation manual



WirelessProfessional

Installation and Software Operation

Contents

1	Information About Using the Operating Instructions	5
1.1	Technical Terms.....	5
1.2	Formatting Conventions.....	5
1.3	Basic Use of the WirelessProfessional Software	5
1.3.1	Tabs and Views	5
1.3.2	Highlighting.....	6
1.3.3	Dragging	8
1.3.4	Context Menu	9
2	Introduction to the WirelessProfessional System.....	10
2.1	Commissioning after Power Supply has Failed	11
2.2	Running Duration Tests.....	12
2.3	Processor-Controlled Emergency Luminaires	12
2.4	Invalid Times due to Flat RTC Battery	12
3	Installation	13
3.1	Before Commissioning the Automatic Test System.....	13
3.2	Using the WirelessProfessional Software	13
3.3	Connecting PC and USB Coordinator	14
3.4	Changing Password	15
3.5	Entering Contact Details and System Names	15
3.6	Installing Devices in the System	16
3.7	Dividing Devices into Groups.....	19
3.8	Maps	21
3.8.1	Integrating Maps	21
3.8.2	Positioning Devices on the Map	23
3.9	Setting up Automatic Test.....	25
3.10	Duration Test during Commissioning.....	26
4	Software Installation	27
4.1	System Requirements.....	27
4.2	Installation	27
5	Software Operation Reference	30
5.1	Symbols	30
5.2	Status Symbols	30
5.3	Operating Statuses	31
5.4	Status Messages.....	32
5.5	Error Messages.....	33
5.6	User Levels.....	34
5.7	“General” View	35

WirelessProfessional

Installation and Software Operation

5.8	"Alarm List" View.....	37
5.8.1	Test Run Progress	39
5.8.2	Communications Log	41
5.8.3	System Log	42
5.9	"Groups" View	43
5.10	"Maps" View	45
5.10.1	"List of Maps" View	46
5.10.2	Graphic "View of Maps"	47
5.11	"Email " View	48
5.12	"Installation " View.....	51
5.12.1	"Configuring Groups" View.....	51
5.12.2	"Test" View.....	57
5.12.3	"Timer" View	59
5.12.4	"Remote Facilities" View.....	61
5.12.5	"System" View	66
5.13	"Network Information" View	69
5.14	"Distributor " View	71
5.15	"Maintenance " View	73
5.16	"Activation" View.....	74
5.16.1	14 Days Trial Version	76
5.17	Device Details Window	77
5.17.1	Device Details Window for Emergency Luminaire	77
5.17.2	Device Details Window for Repeaters	79
5.17.3	Device Details Window for IO Boxes.....	80
5.18	Menus.....	83
5.18.1	File Menu	84
5.18.2	Options Menu	85
5.18.3	Help Menu.....	86
6	Other Software	88
7	Networking Systems	89
7.1.1	IP Address	91
8	Problem-Solving.....	92
8.1	During the Installation, a Device Address is Not Shown in the Unknown Nodes Area	92
8.2	Invalid Devices are Displayed in the Unknown Nodes Area	92
8.3	After the WirelessProfessional Software is Launched, System Remains in Status is being updated Operating Status	92
8.4	Forgotten Facility Manager Password	92
8.5	Forgotten Installer Password.....	93
8.6	Luminaire Not Sending Connection Requests / Not Appearing in Unknown Nodes Area.....	93
8.7	Changing USB Coordinator	93

WirelessProfessional

Installation and Software Operation

9	Technical Data	94
10	Glossary	95
11	Revision History.....	97
12	List of Key Words	98
13	Contact Information	99

1 Information About Using the Operating Instructions

Keep these operating instructions so you can refer to them at a later date!

1.1 Technical Terms

You will find an explanation of all the technical terms used in these operating instructions in the Glossary section.

1.2 Formatting Conventions

- Terms used by the WirelessProfessional software and which you may encounter on the display are printed in bold in the instructions. For example, "Above the **General** view, you will find the **General**, **Alarm List**, **Groups** and **Maps** tabs".

WirelessProfessional software buttons appear with a grey background in the instructions. For example, "Select **Login** and enter the installer password."

1.3 Basic Use of the WirelessProfessional Software

The WirelessProfessional software can be used both via a touchpad / mouse or a touch screen.

1.3.1 Tabs and Views

Figure 1 shows an example of the **General** view used in the WirelessProfessional software. Above the **General** view, you will find the **General**, **Alarm List**, **Groups** and **Maps** tabs. A view is selected by left-clicking or tapping on the corresponding tab above the view.




Figure 1: **General** view

WirelessProfessional

Installation and Software Operation

Page 6

1.3.2 Highlighting

An individual element in a list of elements is highlighted by left-clicking on the element or tapping the element on the touch screen (Figure 2).




Figure 2: One highlighted device

Several elements in a list are highlighted by pressing and holding the Ctrl key and left-clicking on all the elements you want to highlight or tapping them on the touch screen (Figure 3). This kind of highlighting is not possible in tablet mode.




Figure 3: Several highlighted devices

WirelessProfessional

Installation and Software Operation

Page 7

Several consecutive elements in a list are highlighted by clicking on the top element of the range to be highlighted or tapping this on the touch screen, then pressing and holding the Shift key and clicking on the bottom element of the range to be highlighted or tapping this on the touch screen (Figure 4).

All elements in a list are highlighted by left-clicking on the list or tapping the list on the touch screen and then pressing Ctrl+A.

Not all views in the WirelessProfessional software support all these methods for highlighting elements.




Figure 4: Several consecutive highlighted devices

WirelessProfessional

Installation and Software Operation

Page 8

1.3.3 Dragging

Highlighted elements are moved by left-clicking on the highlighted elements and holding down the mouse button. The elements are then dragged to the desired location (Figure 5) and the mouse button is released.

On the touch screen, highlighted elements are moved by touching the highlighted elements with your finger, keeping your finger on the elements and dragging them to the desired location (Figure 5). Once in the desired location, lift your finger off the touch screen.

Alternatively, the highlighted elements can be moved using the context menu. To do this, press the highlighting for a little longer. The context menu opens and the desired function can be selected.




Figure 5: Dragging several highlighted elements

1.3.4 Context Menu

The context menu of an element is opened by right-clicking on the element (Figure 6). On the touch screen, the context menu of an element is opened by touching the element with your finger and keeping your finger on the element until a small square appears on the display. The context menu opens as soon as you lift your finger off the touch screen.



Figure 6: Context menu for a device

2 Introduction to the WirelessProfessional System

The WirelessProfessional system is an Automatic Test System (ATS) for emergency escape lighting in accordance with DIN EN 62034.

Figure 7 shows the components of a WirelessProfessional system and how they interact. The emergency luminaires and other devices establish a radio mesh network to communicate with the automatic test system. The automatic test system comprises a PC with the WirelessProfessional software (Figure 7 no. 4) and USB coordinator (Figure 7 no. 3). The USB coordinator establishes the connection between PC and radio network. The frequency of the radio network is 868 MHz




Figure 7: Setup of a WirelessProfessional system

Each device in the radio network has a send/receive radius (Figure 7 no. 1). The send/receive radius of the WirelessProfessional device is at least 30m indoors.

In order to pass data between two devices in the radio network, the one device must be in the send/receive radius of the other one. All the devices in a system must be linked to the USB coordinator of the automatic test system through an uninterrupted chain of devices, which are able to pass on data.

Figure 8 shows a system in which the radio connection to the three devices to the top right is interrupted. All other devices in the Figure are linked to the USB coordinator through an uninterrupted chain of devices and can communicate with the ATS.




Figure 8: Devices with radio connection to the USB coordinator (green) and devices with interrupted radio connection (red)

Table 1 lists the device types available for WirelessProfessional systems. Only the device types stated may be used for WirelessProfessional systems.

Table 1: Device types of the WirelessProfessional system

Device type	Function
Maintained emergency luminaire	Luminaire for continuous lighting in normal mains power supply and for instances when the power supply to the general lighting fails
Non-maintained emergency luminaire	Luminaire for instances when the power supply to the general lighting fails
IO box	Device with digital inputs/outputs for issuing system statuses and triggering system functions externally
Repeater	Device for bridging the gap between two devices in the radio network if they are outside the send/receive radius

Each WirelessProfessional device has its own four-digit, alphanumerical address. The address can be found on the outside of the WirelessProfessional devices. In the WirelessProfessional software, devices are identified and assigned to the right mounting location by means of their address. A WirelessProfessional system is limited to no more than 1000 devices. A larger number of devices can be split over several WirelessProfessional systems.

2.1 Commissioning after Power Supply has Failed

Should the power supply fail, the emergency lighting transfers to emergency mode. After the power supply has been restored, the PC can be switched on again using the On/Off switch in order for the automatic test system to start up. The Windows user account is logged into automatically and the WirelessProfessional software is launched automatically.

2.2 Running Duration Tests

A duration test of WirelessProfessional emergency luminaires can only be performed if the mains supply has not been interrupted (mains failure, fuse failure, duration test) at least 24h ago.

If a manual duration test is started and one or more emergency luminaires are not adequately charged, the duration test for these emergency luminaires is postponed by 15 minutes. After 15 minutes, another attempt is made to run the duration test for the emergency luminaires. The software will try up to ten times to run a duration test for the emergency luminaires.

2.3 Processor-Controlled Emergency Luminaires

In some WirelessProfessional emergency luminaires, battery charging is controlled by a microprocessor. This prevents function and duration tests from being run if the battery has not been charged to the required end-of-charge voltage. Luminaires with this characteristic are described in the enclosed instructions as a “processor-controlled emergency light” or a luminaire with “integrated SelfControl monitoring”.

2.4 Invalid Times due to Flat RTC Battery

If the following error message appears when launching the Wireless Professional software, the system date is invalid and/or the real time clock battery is flat and needs replacing.




Figure 9: Error message indicating invalid system date

3 Installation

3.1 Before Commissioning the Automatic Test System

Before commissioning the automatic test system, the emergency luminaires and other devices should be installed in the building and their addresses documented in the map. The 3rd address sticker, included in the scope of supply for each device, can be used for this purpose. All emergency luminaires and other devices which are to be added to the safety lighting system during the installation process must be powered from the mains supply.

DIN EN 62034 requires a duration test within the limits of rated duration of emergency operation when commissioning an automatic test system. The batteries of the emergency luminaires must be fully charged for this duration test. Ensure that after commissioning all emergency luminaires have been in mains operation for at least 24h without any interruptions before starting the initial duration test on the automatic test system.

3.2 Using the WirelessProfessional Software

If you are not yet familiar with how to use the WirelessProfessional software, it is essential that you read Section 1.3 about basic use of the software before you start the commissioning process!

3.3 Connecting PC and USB Coordinator

- Connect the PC power supply to a socket and connect the PC to the power supply.
- Connect the USB coordinator to a free USB port on the PC.
- **Important:** Use the USB cable provided to connect the USB coordinator to the PC. Always connect the USB coordinator to the PC directly and not via a USB hub.
- Boot up the PC with the On/Off switch.

The operating system launches automatically with the WirelessProfessional user account and the WirelessProfessional software is launched automatically. The connection to the USB coordinator is established automatically and the display in the application window's title bar changes from **[not connected]** to **[connected and running]**. If the connection to the USB coordinator is not established automatically, change the port manually as described below.

In the top left edge of the screen, click on **Options** and then **Serial Port** or click on the **Installation** tab and then **System (5.12.5)**. This allows you to click on the **Serial Port** button and go to the drop-down menu for the serial port.




Figure 10: Serial Port drop-down menu accessed from Options

In the next window, click on the black arrow to open the drop-down menu, select **USB Serial Port** and confirm with **OK**. The application window's title bar should then have changed to **[connected and running]**.

Note: The COMx details depend on the USB slot selected and so may vary.




Figure 11: Selecting serial port

3.4 Changing Password

- Select **Login** and enter the Installer password. The installer password is preset in the factory to **2222**.
- Go to the **Installation** tab. Select the **System** tab from the bottom set of tabs. Select **Change Installer Password**.




Figure 12: Changing password

- Enter the preset installer password. Enter a new password and re-enter it. Take a note of the new password.




Figure 13: Entering password

3.5 Entering Contact Details and System Names

- Enter your contact details in the **First Name**, **Last Name**, **Company**, **Phone** and **Email** boxes.
- Enter a name in the **System name** box.
- Confirm the entries by clicking on **Save System Data**.

WirelessProfessional

Installation and Software Operation

Page 16

3.6 Installing Devices in the System

- Select **Installation** and **Configure Groups**. The **Unknown nodes** area shows the emergency luminaires and additional devices, which have a radio connection and which are not yet installed in a system. Ensure that all emergency luminaires and additional devices which have been fitted are powered by the mains and wait until all devices are listed in the **Unknown nodes** area.




Figure 14: Devices available

Note: A different process is used to register devices with a wireless module of version 2.0 or higher. If not all devices are displayed in **Unknown nodes**, use the **Find New Devices...** button to start a new search.




Figure 15: Searching for new devices

Confirm the notification by selecting **Yes** to search for new devices on your system.

- Now register all emergency luminaires and additional devices in the system. To do this, highlight all elements in the **Unknown nodes** area and drag the highlighted elements into the **Registered nodes** area or use the context menu to register the nodes.



Warning: During the installation, position the USB coordinator so that it has a direct radio connection with fewer than 50 devices (for details, see Section 5.13).




Figure 16: Highlighting devices available

Note: If you do not want to install all elements from the **Unknown nodes** area: Press and hold the Ctrl key and highlight just those elements you want to add by clicking on the elements and dragging them into the **Registered nodes** area.

- The WirelessProfessional software installs the added emergency luminaires and additional devices in the system. The remaining number of devices not yet installed is displayed in the first line of the **Registered nodes** area (**x devices not associated**). The time needed for this may vary depending on how the devices are arranged in the radio network and how far the installation has progressed (anything from several seconds to several minutes per luminaire).




Figure 17: Associating devices available

WirelessProfessional

Installation and Software Operation

Page 18

- Once all devices have been successfully registered in the system, the first line of the **Registered nodes** area shows the number of emergency luminaires, repeaters and IO boxes installed in the system.




Figure 18: Devices successfully associated

- If you want to change the name of an installed device, open the device's context menu in the **Registered nodes** view and select **Rename 'NAME'**.




Figure 19: Renaming devices

- If you want to switch the operating mode of an emergency luminaire between non-maintained and maintained operation, open the device detail window for the emergency luminaire in the **Registered nodes** area (also refer to Section 5.15.1) by double-clicking with the left-hand mouse button on the name of the emergency luminaire or tapping the name twice.
- Complete installation of the devices in the system by selecting **Save System Data**.

3.7 Dividing Devices into Groups

1. If you want to divide system devices into groups, open the system context menu (first line of **Registered nodes** area) and select **Add Group to 'System'**.




Figure 20: Creating a group

2. Enter the name of the group in the **Add Group to '<System>'** window and then select **OK**.




Figure 21: Group name

The newly added group is added to the list in the **Registered nodes** area in alphabetical order. Under some circumstances, it will therefore not be visible in the part of the list on display.

3. Press and hold the Ctrl key and highlight all elements in the list that are to be added to the new group. Drag the highlighted elements to the new group or use the context menu. If the group is not visible in the part of the list currently on display, scroll through the part you can see until the new group appears by dragging the highlighted elements to the top or bottom edge of the **Registered nodes** area.

WirelessProfessional

Installation and Software Operation

Page 20




Figure 22: Assigning devices to groups

4. Repeat steps 1-3 until all devices are assigned into groups.
5. Complete assignment of the devices into groups by selecting **Save System Data**.

3.8 Maps

The WirelessProfessional software has the option of integrating maps and positioning installed devices within the map. The mounting location of a device can therefore be found quickly when required. The maps must exist in .png, .bmp or .jpg format. The maximum size of the maps is 10 mega pixels. Larger maps cannot be loaded into the WirelessProfessional system.

3.8.1 Integrating Maps

1. Select the **Maps** tab.




Figure 23: Maps in general

2. Open the context menu of the **Maps in system** area and select **Add New Map**.




Figure 24: Adding new map

WirelessProfessional

Installation and Software Operation

Page 22

- Go to the file dialogue for the data carrier on which the maps are located. Highlight the maps you want to add, and confirm the selection by clicking on **Open**.




Figure 25: Selecting files

- Open the context menu of an added map and select **Rename Map <Name>**.




Figure 26: Renaming map

- Enter a meaningful name for the map and confirm the entry by clicking on **OK**.
- Repeat steps 4 and 5 for all maps.

3.8.2 Positioning Devices on the Map

- Select **Toggle Map View**.





Figure 27: Toggling view

1. Select the map on which devices are to be positioned from the drop-down selection box.



WirelessProfessional

Installation and Software Operation

Page 24

2. Use the slide control to adjust the scale and use the scrollbars below and to the right of the map to select the relevant image section.




Figure 29: Scaling view

3. Drag the devices from the left-hand 'Name' area into the map and position them.




Figure 30: Positioning devices

4. Repeat steps 1-3 until all devices are positioned on the maps.
5. Complete positioning of the devices on the maps by selecting **Save System Data**.

Note: Each emergency luminaire and/or each device can only be positioned once and only in one map.

Note: We would recommend regularly saving your changes.

3.9 Setting up Automatic Test

- Select the **Installation** tab. Select the **Test** tab from the bottom set of tabs.
- In the **Capacity test** area in the drop-down **Interval** selection box, select the period between two automatic duration tests for the emergency luminaires. DIN EN 62034 requires a maximum interval of one year between two automatic duration tests.
- Enter the time at which the duration test is to start in the **Time** box. Select a time at which the building is not occupied. Alternatively, DIN EN 62034 allows the duration test to be triggered manually in buildings which may be occupied at any time. In these cases, select **Manually** as the interval.
- In the calendar in the **Start date** box, select the date for the next duration test. Select a date, which is no more than one year in the future.
- In the **Function test** area, also select an interval and time for the automatic function test. DIN EN 62034 requires a maximum interval of one month between two automatic function tests.
- If you have selected **Weekly** as the interval, in the drop-down **Weekday** selection box, select the day of the week on which the function test is to be carried out.
- Complete the settings by clicking on **Save System Data**.
- If necessary, please note other valid national provisions or other provisions required by building law relating to capacity and function tests.




Figure 31: Timer settings

Note: If systems have more than 100 registered luminaires/devices, the command to test them is only sent out for 100 luminaires at a time to reduce the amount of wireless traffic. Testing the next 100 devices starts once testing of the previous 100 devices is complete.

WirelessProfessional

Installation and Software Operation

Page 26

3.10 Duration Test during Commissioning

DIN EN 62034 requires a duration test over the entire assessment period when commissioning an automatic test system. The batteries of the emergency luminaires must be fully charged (at least 24h, see Section 2.2 and 2.3) for this duration test.

- Select the **General** tab
- Press the **Start Duration Test** button

If the batteries of individual luminaires are exhausted before the duration test is completed, repeat the process including a full charge (at least 24h).

To confirm commissioning, reset the maintenance interval by going to "Help" -> "Maintenance" and clicking on the "Confirm Maintenance" button (5.15). The reminder for running maintenance again will start from this time in 365 days.




Figure 32: Starting duration test

4 Software Installation

This section relates to systems supplied without a PC. If systems have been supplied with a PC, the WirelessProfessional software will already be installed on the PC.

4.1 System Requirements

Component	Minimum requirement
Processor	Intel Atom N455 1.6 GHz
RAM	1024 MB DDR3-RAM
Hard disk	32 GB SSD
Display	25.7 cm (10.1") screen size, resolution 1024x600 pixels
Graphics	Intel GMA 3150
Ports	2 x USB 2.0
Operating system	Windows 7/8/10, 32- and 64-bit version

4.2 Installation

- Open the context menu of the **WirelessProfessional_Setup_x.x.exe** file. (**x.x** represents the version number) and select **Run as administrator**.




Figure 33: Selecting installation file

WirelessProfessional

Installation and Software Operation

Page 28

- Enter the administrator password in the dialogue box of the user account controller and confirm with **Yes**.




Figure 34: Entering administrator password

- Select the language to be used during the installation process.




Figure 35: Selecting language

- Select **Next** in the setup dialogue.




Figure 36: Setup dialogue

- Read the information provided about the installation directory and select **Next**.




Figure 37: Setup dialogue

- Select a start menu folder for the program links and then select **Next**.




Figure 38: Setup dialogue

- Select whether a desktop symbol is to be created and then select **Next**.




Figure 39: Setup dialogue

- Select **Install**. The software and the drivers required are installed.




Figure 40: Setup dialogue

- To complete the setup wizards, select **Finish**. The WirelessProfessional software is launched.




Figure 41: Completing installation







Note: The CPC Viewer and CPC File manager programs are needed if remote access to a remote system is to be set up.

5 Software Operation Reference

5.1 Symbols

This section explains the symbols used in the WirelessProfessional software.

Table 2 lists the colour symbols for operating statuses. The priority of a status means that the status with the highest priority is displayed for a device or group for which several statuses apply. For example, the blue colour symbol (emergency luminaire is being tested) would be displayed for a group containing an emergency luminaire with a battery error and an emergency luminaire which is being tested because its priority is higher than that of the red symbol (error message). One exception from this is communication errors, which arise during a test: Should they arise, a red colour symbol is displayed for the device and/or group in question rather than the blue symbol to draw attention to the error.

Symbol		Priority	Meaning
	Yellow	5	Status is being updated
	Blue	4	Emergency luminaire(s) is(are) being tested
	Red	3 ¹	Error message(s)
	Orange	2	Emergency luminaire(s) in remote inhibiting mode
	Green	1	No error message
	Grey	-	Emergency luminaire(s) is(are) masked

¹ Communication errors, which arise during a test, are displayed with a higher priority than the test.

Table 2: Colour symbols

5.2 Status Symbols






Symbol	Meaning
	Maintained emergency luminaire
	Non-maintained emergency luminaire
	The switching status of the emergency luminaire corresponds to its operating mode (switched-on emergency luminaire in maintained operation and/or switched-off emergency luminaire in non-maintained operation)
	The switching status of the emergency luminaire does not correspond to its operating mode (switched-off emergency luminaire in maintained operation and/or switched-on emergency luminaire in non-maintained operation)
	Group/system is linked to the input/output of an IO box

Table 3: Status symbols

5.3 Operating Statuses

Table 4 shows an overview of the special operating statuses of a WirelessProfessional system. Further explanations about the operating statuses can be found in the glossary (Section 10).

Operating status	Non-maintained emergency luminaires, switchable	Maintained emergency luminaires, switchable	Function/duration test possible	Emergency mode possible
Energy save	Off	Off	Yes	Yes
Activate	Off ¹	On	Yes	Yes
Fire alarm	On	On	No	Yes
Block emergency luminaires	Off	On	No	No

¹Switchable non-maintained emergency luminaires are not switched by the **Activate** function. Switched-off emergency luminaires remain switched off and switched-on emergency luminaires remain switched on.

Table 4: Operating statuses

5.4 Status Messages

Table 5 lists the status messages for the WirelessProfessional software and explains the meaning of them.

Status message	Meaning
Starting system	The system is checking that all devices can be reached
Updating	The status of devices is being changed
Device not associated	Device installation in the system is not yet complete
Blocking x luminaires	x emergency luminaires are still to be put into remote inhibiting mode
Unblocking x luminaires	Remote inhibiting mode still needs to be terminated for x emergency luminaires
Emergency state is expiring	Once the fire alarm overrun time has expired, the emergency luminaires are switched off again
Operational	At least one switchable emergency luminaire is switched on
Ready to activate	All switchable emergency luminaires are switched off or the system only consists of luminaires which cannot be switched
Error on x devices	Error messages for x devices
Emergency state is activated by IO-box	Fire alarm (signal at fire alarm input of IO box enabled). All switchable emergency luminaires are switched on.
Emergency state is in follow-up time	Fire alarm terminated (signal at fire alarm input of IO box no longer enabled). The system is in fire alarm overrun time. Switchable emergency luminaires remain switched on until end of overrun time.
Starting test on x devices	Testing of x devices is being started
Test running	Status message during a test
Finishing test on x devices	The test is completed and the test results are being transferred from the emergency luminaires
x luminaires are blocked	x emergency luminaires are in remote inhibiting mode

Table 5: Status Messages

5.5 Error Messages

Table 6 lists the error messages for the WirelessProfessional software and explains the meaning of them.

Error message	Meaning	Possible cause
Device invalid	A device is responding with an unknown type identification	Device firmware is more up-to-date than WirelessProfessional software
Emergency mode / Connection lost	The radio connection to a device is interrupted	Device is in emergency mode Fault in radio connection to device
Battery error	The battery voltage is outside the tolerance range	Battery not connected Incorrect battery connected Battery has suffered excessive discharge Battery defective
requires feature activation	More devices are assigned than the current system configuration is able to manage	
Last test* failed: Connection error	The radio connection was interrupted during the test or once the test was completed	Fault in radio connection to emergency luminaire
Last test* failed: Battery error	Battery error during the test	Battery not connected Incorrect battery connected Battery not charged adequately Battery has suffered excessive discharge Battery defective
Last test* failed: illuminant error	Illuminant error during the test	Illuminant not connected Illuminant defective Switch device defective Illuminant current too low
Last test* failed: not powered long enough	A duration test cannot be carried out because the luminaire had not been charged for long enough	Luminaire connected before less than 24h or recently experienced power supply failure
Last test* failed: Test already running	A test cannot be started because there is already a test running	An attempt was made to start another test even though a test is already running – e.g. automatic duration test underway and manual function test is started. Multiple attempted starts are also possible via the timer.
Last test* failed: Not fully charged	A duration test cannot be carried out because the luminaire had not been charged for long enough	A luminaire with processor-controlled charging is currently charging the battery – e.g. following recent power supply failure
Last test* failed: last capacity test too recent	The luminaires are in the recharge phase following a duration test	An attempt was made to start a function test in the recharge phase

Last test* failed: not associated	Association to luminaire lost	The luminaire was not associated with the system at the start of the test
Last test* failed: emergency active		A test was started while in the fire alarm status (first status emergency mode)

Table 6: Error messages of the WirelessProfessional system

*) – Function or duration test

5.6 User Levels

The rights for accessing the WirelessProfessional software functions are split into several user levels. Table 7 provides an overview of the user levels and their access rights. The **Facility Manager**, **Installer** and **Distributor** user levels are password-protected to prevent unauthorised use. The WirelessProfessional software launches in the **Anyone** user level.

User level	Access rights
Anyone	Read-only, no changes can be made
Facility manager	Switch devices, trigger function/duration tests
Installer	Install devices, configure groups and automatic tests, integrate maps, reset facility manager password
Distributor	Define maintenance intervals, reset installer password, change logo

Table 7: User levels of WirelessProfessional software

5.7 “General” View

You access the **General** view by selecting the **General** tab.

The system name, number of groups and system status are displayed in the **General** view. Figure 42 shows a screenshot of the **General** view for the **Facility Manager** or **Installer** user level. The buttons and their functions do not appear while in the **Anyone** user level. Section 5.1 explains the meaning of the symbols used in the Status column. If there are any active error messages (red colour symbol), the **Alarm List** view can be opened by clicking or tapping on the red colour symbol. The **Groups** view can be opened by clicking or tapping in the **Groups** column.




Figure 42: General view, facility manager and installer user levels

The functions listed in Table 8 can be performed using the buttons in the **General** view.

Button	Function	User level
Activate	Switches on all switchable maintained emergency luminaires	Facility manager, installer
Energy Save	Switches off all switchable and switched-on emergency luminaires	Facility manager, installer
Block emergency luminaires	Puts all emergency luminaires into remote inhibiting mode	Facility manager, installer
Logout	Resets the user level to Anyone	Facility manager, installer
Start function test	Starts a function test for all emergency luminaires	Facility manager, installer
Start Capacity test	Starts a duration test for all emergency luminaires	Facility manager, installer
Reset fire alarm overrun time	Ends the overrun time after a fire alarm. The minimum overrun time is 10 minutes. This button is only enabled if a fire alarm has previously been registered and the emergency luminaires are in the overrun time.	Facility manager, installer

Table 8: Functions of the **General** view

Note: When you log out manually, you will be asked whether you want to save the system. When you log out automatically, you are not asked this.




Figure 43: Save system dialogue

5.8 “Alarm List” View

You access the **Alarm List** view by selecting the **Alarm List** tab.

The **Alarm List** view displays all devices in the system reporting an error. The defective devices are arranged by group. The name of the device as well as its address and status (as colour symbol and in plain text) are displayed. Section 5.1 explains the meaning of the symbols used in the Status column. Section 5.4 contains an overview of the possible error messages. Figure 44 shows a screenshot of the Alarm List view for the **Facility Manager** or **Installer** user level. Not all buttons are available when in the **Anyone** user level.




Figure 44: Alarm List view, facility manager and installer user levels

The functions listed in Table 9 can be performed via the context menu for the error messages (Figure 44).

Note: You can highlight one or more devices at the same time. Instructions about multiple highlighting can be found in Section 1.3.2.

Menu entry	Function	User level
Show device details	Displays detailed information, such as mounting location, operating mode etc. for the selected device	Anyone
Start function test for emergency luminaire <Name>	Starts a function test for this emergency luminaire	Facility manager, installer
Start Duration Test for Luminaire <Name>	Starts a duration test for this emergency luminaire	Facility manager, installer
Block emergency luminaire <Name>	Puts emergency luminaire into remote inhibiting mode	Installer
Unblock	Ends remote inhibiting mode for emergency luminaire	Installer
Show on map <Name>	Shows this emergency luminaire on the map (Luminaire name is stated when the luminaire is assigned to a map)	Anyone

Table 9: Functions of context menu in Alarm List view

A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3).

The functions listed in Table 10 can be performed using the buttons in the **Alarm List** view.

Button	Function	User level
Inspection Log	Opens the test run progress (see Section 5.8.1)	Anyone
Operationtime Log	Not implemented	Anyone
Communications Log	Opens the communications log (see Section Kommunikationslog)	Anyone
System Log	Opens the system log (see Section Systemlog)	Anyone
Start Function Test	Starts a function test for all emergency luminaires	Facility manager, installer
Start Capacity Test	Starts a duration test for all emergency luminaires	Facility manager, installer
Logout	Resets the user level to Anyone	Facility manager, installer

Table 10: Buttons of the **Alarm List** view

A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3).

5.8.1 Test Run Progress

The results of function and duration tests are stored in the test run progress along with other messages. The test run progress is opened by pressing the **Inspection Log** button in the **Alarm List** view. Figure 45 shows a screenshot of the opened test run progress.




Figure 45: Inspection Log

The messages in the test run progress are saved in the **inspection_log.txt** file. If the size of this file exceeds 4 MB, the content of the file is archived under **inspection_log_<Datum>.txt** and removed from the **inspection_log** file. When opened, the last 500 entries from the inspection log are loaded. All entries can be loaded by clicking on the "Load all" button.

The functions listed in Table 11 can be performed using the buttons from the test run progress.

Button	Function	User level
Load all	Loads all the inspection log entries	Anyone
Copy to Clipboard	Copies the test run progress messages to the clipboard	Anyone
Add Message	Manual input of messages. Once a message has been entered manually, the Refresh button must be pressed in order for the message to be listed in the test run progress. Messages entered manually cannot be deleted from the test run progress.	Anyone
Open Old Log	Opens an archived test run progress	Anyone
Refresh	Updates the test run progress messages	Anyone
OK	Closes the test run progress window	Anyone

Table 11: Functions of buttons in test run progress

5.8.2 Communications Log

Error messages from radio network communication are recorded in the communications log. The start time of the WirelessProfessional software and the start time of the connection to a USB coordinator are also recorded. Figure 46 shows a screenshot of the communications log.




Figure 46: Communications Log

The messages in the communications log are saved in the **communication.log** file. If the size of this file exceeds 4 MB, the content of the file is archived under **communication_<Datum>.log** and removed from the **communication.log** file. When opened, the last 500 entries from the communications log are loaded. All entries can be loaded by clicking on the "Load all" button.

The functions listed in Table 12 can be performed using the buttons from the communications log.

Button	Function	User level
Load all	Loads all the communications log entries (Only the last 500 entries are displayed by default)	Anyone
Copy to Clipboard	Copies the test run progress messages to the clipboard	Anyone
Open Old Log	Opens an archived communications log file	Anyone
Refresh	Updates the communications log messages	Anyone
OK	Closes the communications log window	Anyone

Table 12: Functions of buttons in communications log

5.8.3 System Log

All configuration and status changes to the system are recorded in the system log. Figure 47 shows a screenshot of the system log.




Figure 47: System Log

The messages in the system log are saved in the **system.log** file. If the size of the file exceeds 4 MB, the content of the file is archived under **system_<Datum>.log** and removed from the **system.log** file. When opened, the last 500 entries from the system log are loaded. All entries can be loaded by clicking on the "Load all" button. The functions listed in Table 13 can be performed using the buttons from the system log.

Button	Function	User level
Load all	Loads all the system log entries (Only the last 500 entries of the system log are displayed by default)	Anyone
Copy to Clipboard	Copies the system log messages to the clipboard	Anyone
Open Old Log	Opens an old system log file	Anyone
Refresh	Updates the system log messages	Anyone
OK	Closes the system log window	Anyone

Table 13: Functions of buttons in system log

5.9 “Groups” View

You access the **Groups** view by selecting the **Groups** tab.

The **Groups** view shows the groups created in the system as well as the devices in each group. Figure 48 shows a screenshot of the Groups view.




Figure 48: Groups view, facility manager and installer user levels

The groups created in the system are displayed in the top part of the Groups view. The columns in the top part show the name of the group or system, status and number of emergency luminaires, repeaters and IO boxes. Section 5.1 explains the meaning of the symbols used in the Status column. The buttons in the **Maintained Luminaires** and **Non-maintained Luminaires** columns allow emergency luminaires of the respective operating mode to be switched on or off. This function is only available for the facility manager and installer user levels and only if the system contains switchable emergency luminaires. A red frame around the **On** or **Off** button indicates that the emergency luminaires are switched off, in maintained operation or switched on in non-maintained operation.

The functions listed in Table 14 can be performed via the context menu for the groups (Figure 48). The functions take effect for all emergency luminaires within the selected group in each case.

Menu entry	Function	User level
Dimming Settings...	The option of dimming all emergency luminaires in this group when in normal and emergency mode (see Figure 50)	Facility manager, installer
Start Function Test for Group <Name>	Starts a function test for all emergency luminaires in this group	Facility manager, installer
Start Duration Test for Group <Name>	Starts a duration test for all emergency luminaires in this group	Facility manager, installer
Block Group <Name>	Puts all emergency luminaires in this group into remote inhibiting mode	Facility manager, installer
Unblock	Ends remote inhibiting mode for emergency luminaires in this group	Facility manager, installer

Table 14: Functions of context menu in upper part of Groups view

WirelessProfessional

Installation and Software Operation

Page 44

A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3).

The devices of the group selected in the upper part of the Groups view are displayed in the lower part (Figure 49). The name of the device, its address, status, operating mode (if dealing with an emergency luminaire), the position of the luminaire and device type are displayed in the columns of the lower part. The buttons in the **Switch Luminaires** column allow switchable emergency luminaires to be switched on or off. This function is only available at the facility manager and installer user levels and only if the respective emergency luminaire can be switched. A red frame around the **On** or **Off** button indicates that an emergency luminaire is switched off in maintained operation or switched on in non-maintained operation.




Figure 49: Groups view, facility manager and installer user levels

The functions listed in Table 15 can be performed via the context menu for the devices (Figure 49).

Note: You can highlight one or more devices at the same time. Instructions about multiple highlighting can be found in Section 1.3.2.

Menu entry	Function	User level
Device Detail Dialog	Displays details for the selected device	Anyone
Dimming Settings...	The option of dimming this luminaire when in normal and emergency mode (Figure 50: Luminaire dimming settings)	Facility manager, installer
Start Function Test for Luminaire <Name>	Starts a function test for this emergency luminaire	Facility manager, installer
Start Duration Test for Luminaire <Name>	Starts a duration test for this emergency luminaire	Facility manager, installer
Block Luminaire <Name>	Puts this emergency luminaire into remote inhibiting mode	Facility manager, installer
Unblock	Ends remote inhibiting mode for this emergency luminaire	Facility manager, installer
Show on Map	Shows this device luminaire on the map	Anyone

Table 15: Functions of context menu in lower part of Groups view

A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3).




Figure 50: Luminaire dimming settings

Note: If a luminaire supports the dimming function, the **Dimming Settings...** menu item can be selected. If a group contains some luminaires which do not support this feature and some which do, the **Dimming Settings...** menu item is available to the group. Dimming is however only activated on those luminaires which support the feature.

The dimming of emergency luminaires may only be undertaken in accordance with locally valid provisions and the official emergency lighting plan for the building such that sufficient emergency lighting can be guaranteed at all times.

5.10 “Maps” View

You access the **Maps** view by selecting the **Maps** tab.

The **Maps** view allows maps to be added to the system and the luminaires installed in the system to be positioned on the maps such that the mounting location of a luminaire can be found at any time. The functions of the **Maps** view are only available to the **Installer** user level. The maps can only be viewed when in the **Anyone** and **Facility Manager** user levels.




Figure 51: Maps view (list of maps), installer user level

The Maps view is divided up yet further into the list of maps (Figure 51) and graphic view of maps along with the devices positioned within it (Figure 53). You can switch between the two views using the **Toggle Map View** button.

5.10.1 “List of Maps” View

You can add new maps by selecting **Add New Map** in the context menu of the **Maps in system** area (Figure 51). Go to the file dialogue for the data carrier on which the maps are located. Highlight the maps you want to add and confirm the selection by clicking on **Open**. The following graphics file formats are supported: **.bmp**, **.jpg** and **.png**. The maximum size of the maps is 10 mega pixels. Larger maps cannot be loaded into the WirelessProfessional system.

You can sort the list of maps by highlighting an entry and dragging it to the desired position within the list.

The context menu for maps in the **Maps in system** area (Figure 51) contains the **Add New Map**, **Rename Map <Name>**, **Delete map <Name>** and **Switch to Map View of <Name>** functions.

A view of the building can be integrated in the right-hand part of the **List of Maps** view. You add a building view by opening the context menu in the grey rectangle and/or building view at the right-hand edge of the window and selecting **Select New Building Logo** (Figure 52). Go to the file dialogue for the data carrier on which the building view is located. Select the building view and confirm the selection by clicking on **Open**.

Click or tap twice on an entry in the list of maps to go to the graphic view of this map.

Once you have made changes to the maps, select **Save System Data** to confirm the changes.




Figure 52: Maps view (list of maps), installer user level

5.10.2 Graphic “View of Maps”

The devices installed in the system can be positioned on the maps in the graphic view of maps. Figure 53 shows a screenshot of the graphic view of maps.

You access the graphic view of maps by clicking on the **Toggle Map View** button or by double-clicking or tapping twice on an entry in the list of maps.

The devices installed in the system are listed, sorted into groups, in the left-hand part of the view. You position a device on a map by highlighting the device in the left-hand part and dragging it to its mounting location on the map in the right-hand part. Devices which have been positioned on a map are automatically removed from the list in the left-hand part.

The map shown in the right-hand part can be selected from the drop-down selection list above the right-hand part. A map can also be selected using the arrow buttons located to the right and left of the drop-down selection list.

The slide control above the right-hand part can be used to adjust the scale of the map displayed and the scrollbars below and to the right of the map can be used to select the relevant image section.




Figure 53: Maps view (graphic view), installer user level

The functions listed in Table 16 can be performed using the buttons in the graphic view of maps.

Button	Function	User level
Reset Node Positions	Deletes all devices from the map currently on display	Installer
Toggle Map View	Switches between the list and graphic view of maps	Anyone
Save System Data	Saves all changes to the system configuration	Installer

Table 16: Functions of buttons in graphic view of maps

Once you have made changes in the graphic view of maps, select **Save System Data** to confirm the changes.


WirelessProfessional

Installation and Software Operation

Page 48

5.11 "Email " View

You access the **Email** view by selecting the **Email** tab. To be able to see this tab, you must log in at facility manager level or higher.



The screenshot displays the 'Email' configuration window within the 'Wireless Professional' application. The window has a title bar with 'Facility (connected and running)' and standard window controls. Below the title bar is a menu bar with 'File', 'Options', and 'Help'. The main area features a blue header with the 'Wireless Professional' logo and a green emergency exit icon. A tabbed interface at the top includes 'General', 'Alarm List', 'Groups', 'Maps', 'Email' (selected), 'Installation', and 'Network Information'. On the right side of the 'Email' tab, there are buttons for 'Change Facility Manager Password', 'Send Test-Mail', and 'Save System Data'. The configuration fields include: 'Sender' (wirelessprofessional@betreibe.de), 'Subject' (emergency lighting system <facility>), 'Email address' (max.muslermann@abc-technik.de), 'SMTP server' (smtp.betreibe.de), 'SMTP server login' (vpprofessional), 'SMTP server password' (masked with dots), 'Wait time' (5 minutes), 'Radio fault' (checked), 'Number of necessary radio faults' (1), 'Battery fault' (checked), 'Also report temporary faults' (unchecked), 'Mail delivery on function test' (All tests), 'Mail delivery on capacity test' (All tests), 'Blocking luminaire' (unchecked), 'Emergency status change' (unchecked), 'Installer login' (unchecked), and 'Logout time' (1 h).

Figure 54: Email view, facility manager and installer user levels

The WirelessProfessional software provides the option of sending an email to a previously defined email address when certain events occur. The settings for sending these emails can be configured in the Email view. To use this function, you need an email account from which the emails can be sent, and the PC must have an Internet connection. Emails can be sent via a secure SSL connection.

Figure 54 shows a screenshot of the Email view.

Table 17 lists the boxes in the Email view and their meanings.

Box	Meaning
Sender	Sender's email address
Subject	Entry in subject line of email
Email address	Receiver's email address Use commas if sending to several different email addresses, e.g. receiver1@domain1.de , receiver2@domain2.de , ...
SMTP server	SMTP server from which the emails are sent
Port	The port via which the emails are to be sent (usually port 25, 587 or 465)
SMTP server login	Login for the SMTP server
SMTP server password	Password for the SMTP server. The WirelessProfessional software only supports SMTP servers with a password login.
Wait time	Time after an event has occurred before an email is sent. During this time, the system waits for further events so that several events can be bundled in one email.
Radio fault	Email dispatch in the event of a radio fault
Battery error	Email dispatch in the event of a battery fault
Also report temporary faults	An email is sent even if the fault has been remedied before the end of the wait time.
Mail delivery on function test	Choose between Email is sent after all function tests (all tests) Email is only sent after function tests in which errors occurred (failed tests) Emails are not sent after function tests (never)
Mail delivery on capacity test	Choose between Email is sent after all duration tests (all tests) Email is only sent after duration tests in which errors occurred (failed tests) Emails are not sent after duration tests (never)
Blocking luminaire	Email is sent when emergency luminaire(s) is(are) put into remote inhibiting mode
Emergency status change	Email is sent when the signal status at the fire alarm input on the IO box changes (fire alarm starting or fire alarm ending)
Installer login	Email is sent when a user logs in as installer
Logout time	Users logged in as facility manager or installer are automatically logged out if no user activity is detected for the time set here. This function serves to automatically log out facility managers or installers who have forgotten to log out.

Table 17: Boxes in Email view

The functions listed in Table 18 can be performed using the buttons in the Email view.

Button	Function	User level
Change Facility Manager Password	Change the password for the facility manager user level	Facility manager, installer
Send Test Mail	Sends a test email	Facility manager, installer
Save System Data	Saves all changes to the system configuration	Facility manager, installer

Table 18: Functions of buttons in Email view

Once you have made changes in the Email view, confirm the changes by clicking on the **Save System Data** button.

5.12 “Installation ” View

You access the **Installation** view by selecting the **Installation** tab. The **Installation** tab is only available at the installer user level.

The Installation view is divided up into the **Configure Groups**, **Test**, **Timer**, **Remote Facilities** and **System** views using tabs.

5.12.1 “Configuring Groups” View

You access the **Configure Groups** view by selecting the **Configuring Groups** tab in the **Installation** view. The **Configure Groups** view allows new devices to be added to the system and groups to be created and managed. Figure 55 shows a screenshot of the **Configure Groups** view.



Figure 55: Configuring Groups view, distributor user level

The first line in the **Registered nodes** area shows the name and properties of the system. Under this you can see the groups created in the system and the devices in the groups. Click or tap on the triangle to the left of a group to expand this group and display the devices in this group or to collapse this group again.

The columns in the **Registered nodes** area show the name of the group or device, status and number of **emergency luminaires**, **repeaters** and **IO boxes** in the group.

Section 5.1 explains the meaning of the symbols used in the Status column.

The functions listed in Table 19 can be performed via the context menu for the entries in the **Registered nodes** area (Figure 56). The context menu entries vary depending on whether the context menu for a group or device is called up.

At distributor user level, the Address column also shows information about the version of the wireless module fitted in the device.

WirelessProfessional

Installation and Software Operation

Page 52




Figure 56: Configuring Groups view - context menu

Menu entry	Function	User level
Mask x luminaires, x repeaters and x IO boxes/Mask luminaire 'Name'	Masks the device/devices (errors are not shown)	Installer
Unmask Devices	Cancels the masking of masked devices	Installer
Start Function Test for Luminaire 'Name'/ for Group 'Name'	Starts a function test for this emergency luminaire/emergency luminaires in this group	Installer
Rename group 'Name' / luminaire 'Name'	Renames groups/emergency luminaires	Installer
Add Group	Adds a sub-group to a group and/or system. This function is only enabled in the context menu for groups/the system	Installer
Delete group 'Name' / luminaire 'Name'	Deletes the group/device from the system	Installer
Set duration test duration for group 'Name' / luminaire 'Name'	The option of shortening the autonomy time (and/or test duration) of the selected luminaire or all luminaires in a group from the control centre. See note	Installer

Table 19: Functions of context menu in Registered Nodes area, Configuring Groups view

If the context menu of the **Set duration test duration for luminaire 'Name'** is selected, the **Autonomy time settings** window opens (Figure 57).




Figure 57: Autonomy time settings window

The current autonomy time is shown in the **Autonomy time settings** window. A new autonomy time can be selected using the drop-down list.

Only an autonomy time, which is the same as or shorter than the initial autonomy time, can be selected here.

This may result in an increase in the light current.

Warning: Changes to the autonomy time of emergency luminaires may only be made in accordance with locally valid provisions and the official emergency lighting plan for the building such that sufficient emergency lighting can be guaranteed at all times.

Note: Autonomy time settings are supported in wireless module version 2.1 (15) and higher. If the luminaire does not support this function, this menu item is not available. If a group contains both some luminaires which do not support this feature and some which do, this menu item is available. If the menu item for setting the duration test duration for luminaires is selected for such a group, a note appears informing the user of which devices do not support this feature. The autonomy time for the remaining devices can be changed by pressing the **Yes** button.




Figure 58: Note relating to changing the autonomy time

The luminaire(s) then changes(change) briefly into the Refresh status. As soon as the luminaire(s) returns(return) to the OK status, the change takes effect and is displayed accordingly in the device details (see Figure 87).

The **Unknown nodes** area shows the devices, which have a radio connection and which are not yet registered in a system. The list of devices are split into the **Luminaires**, **Repeaters** and **IO boxes** device types. Devices which are not supported by the installed version of the WirelessProfessional software are shown as **Not usable** in the **Unknown nodes** area. Devices where the radio connection has been interrupted for more than 5 minutes are removed from the **Unknown nodes** area.00

Devices from the **Unknown nodes** area are added to the system by highlighting them in the **Unknown nodes** area (Figure 59) and dragging them into the **Registered nodes** area. The devices are then installed one after another in the system. The remaining number of devices not yet installed are displayed in the first line of the **Registered nodes** area (**x devices not associated**). The time needed for this may vary depending on how the devices are arranged in the radio network and how far the installation has progressed (anything from several seconds to several minutes per luminaire).




Figure 59: Configuring Groups view, installer user level



Warning: During the installation, position the USB coordinator so that it has a direct radio connection with fewer than 50 devices (for details, see Section 5.13, "Network Information").

Devices, which have been installed in a system, only pass on data packages from devices in the same system. If devices are added to a system individually, the following scenario may therefore arise: A device, which is mounted a long way from the USB coordinator, is added to the system. The devices, which are mounted between this device and the USB coordinator which are needed to pass on data packages may however not yet have been installed in the system. The distant device may then not be contactable in the radio network. This is the reason why all devices that are to be installed in the system should be highlighted in the **Unknown nodes** area and at the same time dragged into the **Registered nodes** area.

The functions listed in Table 20 can be performed via the context menu for the entries in the **Unknown nodes** area (Figure 60).




Figure 60: Configuring Groups view - context menu

Menu entry	Function	User level
Add to group	Adds the selected device to a group	Installer
Delete Device 'Address'	Deletes the device from the Unknown nodes area	Installer
Add New Luminaire	Add emergency luminaire manually	Installer
Add New Repeater	Add repeater manually	Installer
Add New IO Box	Add IO box manually	Installer

Table 20: Functions of context menu in **Unknown nodes** area, **Configuring Groups** view

The **Add to group** function allows to add devices to groups (1.3.3).

The **Delete Device 'Address'** function deletes the device from the **Unknown nodes** area. This simply removes the device from the list. Should the device continue to transmit connection requests, the address will be displayed again.

The **Add New Luminaire/New Repeater/New IO Box** functions allow devices to be added to the system manually without there being any radio contact with these devices. The device addresses must be known in order to add devices manually.




Figure 61: Address for the New Device

Manually created devices can also be dragged out of the **Unknown nodes** area into the **Registered nodes** area just like other devices.

WirelessProfessional

Installation and Software Operation

Page 56

Important!

Manually created devices can only be added provided that there are fewer than 250 devices in the system.

The colour status of manually added devices remains yellow until there is radio contact with the device. Then it changes to green. This function can be used to create an emergency lighting system in the WirelessProfessional software without the user having to be physically at the system's mounting location.

If a 4-character device address is entered in the **Address for the New Device** window and **Delete** is pressed, the system ID is removed from the device with this address. While the system ID is being removed, the device is displayed with the name **TempNode[Address]** (Figure 62) and once the system ID has been removed from the device, it is automatically removed from the system.




Figure 62: Display showing device to be deleted

5.12.2 "Test" View

You access the **Test** view by selecting the **Test** tab in the **Installation** view.




Figure 63: Test view, installer user level

The WirelessProfessional system performs automatic tests on safety lighting systems in accordance with DIN EN 50172 and DIN EN 62034. The duration test and function test can be configured in the **Test** view. Figure 63 shows a screenshot of the **Test** view.

Table 21 lists the boxes in the **Capacity test** area and their meanings.

Box	Meaning
Interval	Interval between two duration tests. Choose between manual, quarterly, every 4 months, every 6 months, yearly. If manual is selected, the automatic test is deactivated
Time	Time at which the test starts. Select a time at which the building is most probably not being used.
Part 1	Not implemented
Part 2	Not implemented
Interval between parts	Not implemented
Start date	Select the date for the next duration test
Next capacity test	The date of the next duration test is only displayed once changes have been confirmed by selecting Save System Data

Table 21: Boxes in Test view, Capacity test area

A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3).

If an automatic duration test is started and one or more emergency luminaires are not adequately charged (see Sections 2.2 and 2.3), the duration test for these emergency luminaires is postponed by 24 hr. After 24 hr, another attempt is made to run the duration test for the emergency luminaires. The software will try up to three times to run a duration test for the emergency luminaires.

Table 22 lists the boxes in the **Function test** area and their meanings.

Box	Meaning
Interval	Interval between two function tests. Choose between manual, daily and weekly. If manual is selected, the automatic test is deactivated.
Time	Time at which the test is started. Select a time at which the building is most probably not being used.
Weekday	Day of the week on which the function test is carried out (if weekly is selected in the Interval box)
Next function test	The date of the next function test is only displayed once changes have been confirmed by selecting Save System Data

Table 22: Boxes in Test view, Function test area

Once you have made changes in the Test view, select [Save System Data](#) to confirm the changes.

5.12.3 “Timer” View

You access the **Timer** view by selecting the **Timer** tab in the **Installation** view.

Timers can be used to assign functions to luminaires, which are carried out at defined times. Figure 64 shows a screenshot of the **Timer** view.




Figure 64: Timer view, installer user level

The functions listed in Table 23 can be performed using the buttons in the **Timer** view.

Button	Function	User level
New Timer	Opens the Configure Timer window (Figure 65) to configure a new timer	Installer
Configure Timer	Opens the Configure Timer window (Figure 65) for the highlighted timer	Installer
Activate/Deactivate Timer	Activates/deactivates the highlighted timer	Installer
Delete Timer	Deletes the highlighted timer	Installer

Table 23: Functions of the Timer view

The **New Timer** and **Configure Timer** buttons open the **Configure Timer** window (Figure 65) for configuring a timer. Table 24 lists the boxes in the **Configure Timer** window and their meanings.




Figure 65: Configure Timer window

Box	Meaning
Name	Name of timer
Start Date	Date from which the timer is active
End Data	Date after which the timer is no longer active
Switch-On Time	Time at which the emergency luminaires are switched on
Switch-Off Time	Time at which the emergency luminaires are switched off
Days	Select the days on which the switching function is to be run or select Daily
Operating Mode	Select the switching function to be run. Choose between: Switch Maintained Luminaires Switch Non-Maintained Luminaires Energy Save (switches off all switchable and switched-on luminaires in the system) Activate (switches on all switchable luminaires in the system in maintained operation) Function Test (trigger a manual function test for selected groups) Duration Test (trigger a manual duration test for selected groups)
Groups switch	to Select the groups whose luminaires are to be switched

Table 24: Boxes in **Configure Timer** window

Once you have made changes in the **Timer** view, select **Save System Data** to confirm the changes.

Note: Only the switch-on time should be set for function and duration tests. Otherwise, an error message will appear.




Figure 66: Timer programming error

Timer-controlled function and/or duration tests should be used if small test groups are needed. Manual testing is carried out on a selection of luminaires.

Note: If there are two timers triggering function tests, an interval of 1h must be programmed between them.

Name	Groups	Schedule	Operating Mode	Timer Activated
1 Timer01	<Facility>	off 06:00, on 18:00, daily, 1 Jan - 31 Dez	Switch Maintained Luminaires	yes
2 Timer02	<Facility>	on 00:00, Tu, 1 Jan - 31 Dez	Switch Maintained Luminaires	yes
3 Timer03	<Facility>	on 00:00, We, 1 Jan - 31 Dez	Switch Maintained Luminaires	yes
4 Timer04	<Facility>	on 00:00, Th, 1 Jan - 31 Dez	Switch Maintained Luminaires	yes
5 Timer05	<Facility>	on 00:00, Fr, 1 Jan - 31 Dez	Switch Maintained Luminaires	yes
6 Timer06	<Facility>	on 00:00, daily, 1 Jan - 31 Dez	Switch Maintained Luminaires	activation required

Figure 67: Overview of programmed timers

The number of timers which can be programmed is limited to 5 by default and can be extended by means of activation. For more information about extending the system, please contact your distributor.

5.12.4 "Remote Facilities" View

You access the **Remote Facilities** view by selecting the **Remote Facilities** tab in the **Installation** view. In addition to its own devices, the WirelessProfessional software can also monitor a WirelessProfessional control centre connected via Ethernet.

WirelessProfessional

Installation and Software Operation

Page 62




Figure 68: Remote Facilities view, installer user level

The **New Remote Facility** button opens the window for configuring networked systems.




Figure 69: Input box for remote facility

Enter any name for the system you want to monitor (for example: WLTOUCH). In the “Remote computer” box, enter the IP address or device name of the system in question and the port. Then select the **Test Connection** button to test the connection to it.

- Default port for WLCPC: 80
- Default port for systems in the multiControl *plus* series: 81

Once the connection to the system you want to monitor is established successfully (●), configure the update delay. This is used to set how often data from the remote system is queried. You can choose between 10 seconds, 1 minute and 10 minutes.

When VNC access is activated, you can establish a direct connection with the system in question and operate it using remote control by double-clicking or tapping on it twice. For the remote connection, you will need:

- the TigerVNC Server to be running on the device you want to monitor
- TigerVNC Viewer to be installed on the device you want to monitor

(Is pre-installed or supplied as a setup under c:\WirelessProfessional\CPC Tools\TigerVNC\windows\).

Once all the configurations are complete, confirm with **OK**.

Note: A remote facility may be a system from the multiControl *plus* series (XML version 1) or a Wireless-Professional system. The type of remote access can also be selected.




Figure 70: Connection test for remote facility

WirelessProfessional

Installation and Software Operation

Page 64

All the systems to be monitored are listed along with their name, IP address and status. The configuration menu of the system in question can be called up again and edited by selecting the **Edit Remote Facility** button. Systems highlighted accordingly can be removed from monitoring by selecting the **Delete Remote Facility** button.

The VNC Viewer's file path can be selected using the button in the bottom right. The VNC Viewer folder is usually located at C:\Program Files\TigerVNC. Select the vncviewer.exe file and click on Open. If the installation path differs from the default one, select the path accordingly.




Figure 71: Overview of remote facilities

The number of systems which can be monitored is limited to 1 by default and can be extended by means of activation (see Section 5.16).

For more information about extending the system, please contact your distributor.

In the General view, along with the main system you will now also see the systems to be monitored by the main system.




Figure 72: Monitoring of remote facilities

Remote access to the system in question is established by double-clicking or tapping twice in the “No. Groups” or “Status” column of the respective system.




Figure 73: VNC Client started

When the password prompt appears, unless you have changed it, enter the default password “123456” and confirm with OK.




Figure 74: Entering password for VNC Client

You now have complete access to the remote system in the window on screen.

WirelessProfessional

Installation and Software Operation

Page 66




Figure 75: Access to remote facility

5.12.5 "System" View

You access the **System** view by selecting the **System** tab in the **Installation** view. In the System view, contact details for the installer are entered and other settings affecting the entire system are configured. Figure 76 shows a screenshot of the **System** view.

Table 25 lists the boxes in the **System** view and their meanings.

Box	Meaning
First name, Last name, Company, Phone, Email	Installer's contact details. These contact details are displayed in the Maintenance Due reminder window.
System name	Name of the WirelessProfessional system
Project name	Name of the project
Time to connection error	Time between a radio fault occurring and an error being reported. This parameter applies to all devices other than IO boxes.
Time to connection error for IO Boxes	Time between a radio fault to an IO box occurring and an error being reported. Alongside the error message, the relay of output 1 on the IO box (event device error function) also de-energises.
Fire alarm overrun time	Time between the fire alarm signal being deactivated and the emergency luminaires being switched off. If Manual Retraction is selected, the overrun time has to be manually terminated using the Reset fire alarm overrun time button in the General view.
Commands waiting	Number of commands which are still waiting to be transmitted to a device
Commands in execution	Number of commands in the USB coordinator's output buffer

Table 25: Boxes in System view

The longer of the two **Time to connection error** or **Time to connection error for IO Boxes** times is also the minimum period for which the automatic test system remains in the **Starting system** operating status (colour symbol 🟡) after a reboot. The system cannot switch to the **No error message** status (colour symbol 🟢) before this time due to an error being present before the time when the system launches this will result in an error message after the **Time to connection error** time.




Figure 76: System view, installer user level

If installation has been interrupted or if the coordinator is changed, the system ID must be re-entered in all devices. This is done using the **Reconnect All Devices** button. During this process, the system assignment is temporarily deleted from the devices. They will continue to be shown in the **Registered nodes** area. Devices of other systems within range are temporarily shown in the **Unknown nodes** area (8.7).



Warning: The **Reconnect All Devices** function is performed in all other systems within range. Given that this process involves a high volume of radio traffic, it may take several hours to complete. Once you have made changes in the **Configuring Groups** view, select **Save System Data** to confirm the changes. The functions listed in Table 26 can be performed using the buttons in the **System** view.

Button	Function	User level
Serial Connection...	Manual selection of port for USB coordinator	Installer
Change Installer Password	Change the installer password	Installer
Reset Facility Manager Password	Reset the facility manager password to 1111	Installer
Import Inspection Log	Not implemented	Installer
Export Groups	Exports the group structure into a file with comma-separated formatting (comma separated values, csv)	Installer
Reconnect All Devices	All devices assigned to the system are allocated the system ID of the coordinator currently connected	

Table 26: Functions of the System view


Once you have made changes in the System view, select **Save System Data** to confirm the changes.

5.13 “Network Information” View

You access the **Network Information** view by selecting the **Network Information** tab. The **Network Information** tab is only available at the **Installer** and **Distributor** user levels.

The top part of the **Network Information** view shows the radio signal strength of the devices, which have a direct radio connection to the USB coordinator. The devices with a direct radio connection to the USB coordinator are highlighted in Figure 77. Figure 78 shows a screenshot of the **Network Information** view. The height of the bar indicates the radio signal strength. The device addresses are displayed above the bar.

Once a signal from a device has been received and the radio signal strength measured, a 4-minute timer is started. While the timer is running, the colour of the radio signal strength bar for this device changes from green to grey. If the 4-minute timer has expired without a new measurement being taken for the device, the device is removed from the view.



1. Device with a direct radio connection to the USB coordinator
2. USB coordinator
3. Computer
4. Device with a direct radio connection to the USB coordinator

Figure 77: Devices with a direct radio connection to the USB coordinator

WirelessProfessional

Installation and Software Operation

Page 70




Figure 78: Network Information view, installer user level

The bottom part of the **Network Information** view serves to measure various radio network parameters. This can be useful for problem-solving. If a measurement is needed, the distributor will handle this or will ask you to take the measurement and provide him or her with the results.

Start the measurement by selecting the **Measure 1 Minute**, **Measure 10 Minutes** or **Measure 1 Hour** button.

Before starting a measurement lasting more than one hour, set the logout time in the Email view to **never** and confirm the change with **Save System Data**.

Table 27 lists the measurements and their meanings.

Measurement	Meaning
Packets from directly connected nodes	Number of radio packets per minute from devices with a direct radio connection to the USB coordinator. The colour symbol of this measurement turns yellow or red if too many devices have a direct radio connection to the USB coordinator.
Total requests received	Total number of requests per minute from devices to the automatic test system
Association requests received	Number of requests per minute from devices not yet installed in a system.
Heartbeats received	Radio network measurement
Total requests sent	Number of requests per minute from the automatic test system to devices
Total request error rate	Percentage of requests, which cannot be transmitted to the devices.
USB error rate	Percentage of requests, which cannot be transmitted to the USB coordinator via the USB connection.

Table 27: Measurements in the bottom part of the **Network Information** view

5.14 "Distributor " View

You access the **Distributor** view by selecting the **Distributor** tab. The **Distributor** tab is only available at the distributor user level.

In the **Distributor** view, the contact details and logo of the distributor are entered and other settings affecting the entire system are configured. Figure 79 shows a screenshot of the **Distributor** view.

Table 28 lists the boxes in the **Distributor** view and their meanings.

Box	Meaning
Company, Contact person, Phone, Email	Distributor's contact details. These contact details are displayed in the Maintenance Due reminder window.
Logo	Logo, which is displayed in the WirelessProfessional software between the menu bar and General, Alarm list etc. tabs. If the distributor does not load his or her individual logo, the WirelessProfessional logo is displayed. Figure 79 shows the Distributor view along with the distributor's logo. Pressing the Search button opens a window for selecting the logo file from within the directory structure. The logo is only adopted in the display once the Save System Data button has been clicked on. The Reset button resets the logo to the WirelessProfessional logo.
Maintenance notification	The WirelessProfessional software displays maintenance notifications at the times defined by the maintenance interval. The Maintenance view can only be called up via the Help menu if Maintenance notification is selected.
Next maintenance	Time at which the WirelessProfessional software displays the reminder window for the system maintenance due. Once maintenance has been completed, the date for the next maintenance is increased according to the maintenance interval.
Maintenance interval	Time between completed maintenance and the next maintenance notification.
Maintenance password protected	Password that has to be entered in the Maintenance view in order to confirm maintenance. The maintenance password is generated automatically by the WirelessProfessional software from the address of the USB coordinator and cannot be chosen by the user.
Maintenance plan 1-3	File paths to the maintenance plans and texts of links to the maintenance plans in the Maintenance view
Send maintenance emails	If the checkbox is ticked, sends emails containing a reminder that the maintenance date is due.
Reduce duration test duration	The time over which the duration test is run can be reduced here from the full measurement period to 2/3 of the measurement period.

Table 28: Boxes in Distributor view

WirelessProfessional

Installation and Software Operation

Page 72




Figure 79: Distributor view, distributor user level

The functions listed in Table 29 can be performed using the buttons in the **Distributor** view.

Button	Function	User level
Acknowledge Tests	Removes all entries of failed test results (duration test, function test) from the Alarm List view. The failed test results are not removed from the test run progress and the fact that the Acknowledge Tests function has been run is entered in the test run progress. Should there be emergency luminaires with a failed test result, the test in question assumes an orange colour symbol in the device details window for the emergency luminaire and the error is displayed as "acknowledged" when the cursor is held over the colour symbol. The Acknowledge Tests function serves to allow the distributor to exit the customer's system without error messages if an error has arisen during a duration test and the error has been remedied but the emergency luminaires need charging for 20 h before the next duration test.	Distributor
Reset invalid devices	Registers the firmware of invalid devices in the system. The Invalid device error message may appear if the firmware of a device already installed in the system is being updated.	Distributor
Change Distributor Password	Change the distributor password	Distributor
Reset installerpassword	Reset the installer password to 2222	Distributor
Save System Data	Saves changes to the system	Distributor

Table 29: Functions of the Distributor view

5.15 “Maintenance ” View

The **Maintenance** view can only be reached via the **Help** menu or the maintenance notification. The **Maintenance** entry in the **Help** menu is only enabled if the distributor has activated the maintenance function. The **Maintenance** view can be seen at all user levels. Figure 80 shows a screenshot of the **Maintenance** view.




Figure 80: Maintenance view, facility manager, installer or distributor user level

Click or tap on the **Maintenance plan in English** link to open the corresponding maintenance plan. The maintenance plan contains detailed instructions about how to maintain the system.

One element of maintenance is checking that the relays of the IO boxes are fully functional. The system's IO boxes are listed in the **IO Boxes** area. Double-clicking or tapping twice on the entry for an IO box in the **IO Boxes** area opens the device details window for this IO box. The relays can be switched over for the check using the **T** buttons in the Configuration view (also refer to Section 5.17.3).

Selecting the **Confirm Maintenance** button ends the maintenance, closes the maintenance window and increases the timer for maintenance to the next maintenance date. In some circumstances, the **Confirm Maintenance** button is password protected. On the left-hand side of the **Maintenance** view, enter the maintenance password before ending maintenance with **Confirm Maintenance**.

WirelessProfessional

Installation and Software Operation

Page 74

5.16 “Activation” View

If a function in the system requires activation, one of the places where this is indicated is in the alarm list for your system. To see this, click on the **Alarm List** tab. These messages are also displayed under the **Groups** and **Installation, Configuring Groups** menu items.




Figure 81: Activation required

To open the activation menu, right-click on **Help** and then on **Activation** in the drop-down list which opens.




Figure 82: Accessing Activation menu

The current actual system status (default delivery status: 250 devices, 5 timers, 1 device which can be monitored) is displayed here and you can enter an activation code to increase the max. number of devices which can be monitored, the number of timers which can be used and the number of remote systems you want to monitor.

Select the features you want to activate by clicking in the circles next to the corresponding option. A request code is generated under "Request Activation Code" using the features you have put together that you want to activate.

Several features can be requested with one request code.

Please send this code to your distributor. Your distributor will send you the activation code you can use to activate and use the features you requested.

You can use the **Copy to Clipboard** button to manually add the request code to an email, for example. Pressing the **Send email...** button automatically sends the request code to the email address stored for the distributor. The **Save as file...** button allows you to save the request code as a text file.




Figure 83: Overview of Activation menu

Now enter the activation code, which you received from your distributor. If successful, you will get the following message.




Figure 84: Features successfully activated

If an invalid code is entered, this error message appears.




Figure 85: Invalid activation code

If WirelessControl devices (devices up until April 2016) are assigned to your system, a warning symbol will appear in the Activation menu. Information telling you which devices comply with the WirelessControl specification can be found under **Details**.

WirelessProfessional

Installation and Software Operation

Page 76

Note: If the list is empty, only the coordinator does not comply with the WirelessProfessional specification.

Note: Activation for additional luminaires, remote facilities or timers is indicated by the ID of the associated coordinator. This means that a system can be easily moved to a new PC without the activations being lost. If you want to change the coordinator, please contact your distributor. When updating to Wireless Professional 2.3., activations in place are linked to the associated coordinator.




Figure 86: Overview of Wireless Control devices

5.16.1 14 Days Trial Version

Press the **14 Day(s) Trial Version** button to activate all features of the WirelessProfessional for free for a period of 14 days. You can test all the features for free during this time. Once the trial period is over, all non-activated features are blocked.

You will find information about the remaining trial period in the Activation menu.

Note: This activation can only be undertaken once!

5.17 Device Details Window

Click or tap twice on a device entry in the **Alarm List**, **Groups** or **Configuring Groups** views to open the device details window for the device. This window differs depending on the device type.

The device details window can be opened at all user levels. However, the entries can only be edited at **Installer** user level.

5.17.1 Device Details Window for Emergency Luminaire

The device details window for emergency luminaires allows the name/mounting location of the emergency luminaire to be entered and the operating mode to be switched between non-maintained and maintained operation. The position of the emergency luminaire on the map, its address and the results of the last three tests are displayed in the details window. If you hover the cursor above one of the colour symbols of the test results or tap on them, the time of the test and the result are displayed in plain text.

The luminaire transfers the time of the last reset to the control centre. A reset happens when the power supply fails (excessive discharge).

The Information tab contains not only information about the set operating mode and set duration for tests but also information about the up time. The up time indicates the time since the last power supply failure or luminaire reset. A duration test is only carried out after an up time of more than 20 hours.

The screenshot shows a 'Device Details' window for a device named 'Notleuchte001'. The window has two tabs: 'General' and 'Information'. The 'Information' tab is selected. Under the 'Settings' section, there are fields for 'Position' (containing 'Notleuchte001'), 'Operating mode' (a dropdown menu set to 'Non-maintained Luminaire'), 'Position on map' (displaying '----'), and 'Address' (displaying 'J2UU'). Below the settings is a 'Test results' section with a table of test outcomes. The table has four columns: 'Succeeded' (green circle), 'Failed' (red cross), 'Failed, but Confirmed' (yellow triangle), and an empty column. The rows show the results of the last three manual function tests and the last three automatic capacity tests, all of which are 'N/A'. At the bottom right of the window are 'OK' and 'Cancel' buttons.

Succeeded	Failed	Failed, but Confirmed	
Last 3 manual function test results:	N/A	N/A	N/A
Last 3 manual capacity test results:	N/A	N/A	N/A
Last 3 automatic function test results:	N/A	N/A	N/A
Last 3 automatic capacity test results:	N/A	N/A	N/A

WirelessProfessional

Installation and Software Operation

Page 78




Figure 87: Device details window for emergency luminaire

Device type	Function
Maintained emergency luminaire	Luminaire for continuous lighting and for instances when the power supply to the general-purpose lighting fails
Non-maintained emergency luminaire	Luminaire for instances when the power supply to the general-purpose lighting fails

5.17.2 Device Details Window for Repeaters

In the **Device Details window** for repeaters, you can set the name/mounting location of the repeater and display its position on the map as well as its address.




Figure 88: Device Details window for repeaters

5.17.3 Device Details Window for IO Boxes

In the General view in the Device Details window for IO boxes, you can set the name/mounting location of the IO box and display its position on the map as well as its address. The current status of the mains voltage at the IO box, the switching status of the three outputs (K1-K3) and two inputs (E1, E2) can also be shown using the same colours as the displays on the IO box.




Figure 89: Device Details window for IO boxes, General view

The IO box's inputs and outputs can be configured in the **Configuration** view of the Device Details window for IO boxes.




Figure 90: Device Details window for IO boxes, Configuration view

In the **Configuration** view, select the **K2** or **K3** buttons to configure outputs 2 or 3 on the IO box. Figure 90 shows the window for configuring the outputs. The event required to trigger the output switching, is selected in the **Output State** area. Table 30 explains the meanings of the events listed. In the **Groups applying** area, you can select the groups in which the selected event has to occur in order for the output to be switched. If **Energy Save / Activate**, **Manual Fire Alarm Active** or **Disabled** is selected as the event, the groups selection is disabled because these events always affect the entire system.




Figure 91: Configuring the IO box output

Event	Function
Test Running	Output is switched for the duration of the test
Last Test Failed	Output is switched as a result of a failed test
Maintained Luminaires switched	Output is switched if at least one maintained emergency luminaire is switched off
Non-Maintained Luminaires switched	Output is switched if at least one non-maintained emergency luminaire is switched on
Luminaires Blocked	Output is switched if at least one emergency luminaire is in remote inhibiting mode
Energy Save / Activate	Output is switched if all switchable emergency luminaires are switched off
Manual Fire Alarm Active	Output is switched if the signal at the fire alarm input on the IO box is enabled
Disabled	Output is disabled

Table 30: Output states of outputs

Output 1 (K1) is always allocated the **Event Device Error** function and cannot be configured. The relay of output 1 de-energises as soon as a device in the system reports an error. The relay of output 1 will only de-energise with the **time to connection error for IO boxes** delay if the radio connection between the IO box and automatic test system is interrupted. The **time to connection error for IO boxes** duration is set in the **Installation/System** view (Section 5.12.5).

The function of the output relays can be checked by pressing the **T** buttons in the **Configuration** view. The **T** buttons switch over the relay of the respective output. As soon as the **Configuration** view is exited, the relays of outputs K1-K3 are reset to the switching state and matches the configuration of the respective output.

In the **Configuration** view, select either the **E1** or **E2** button to configure the inputs on the IO box. Figure 92 shows the window for configuring the IO box inputs. A name can be assigned in the **Input Name** area. The process is triggered by the signal at the input and is selected in the **Operating Mode** area. Table 31 explains the operating modes of the inputs. In the Logic level area, select whether the event is triggered by a high level (high-active) or by a low level (low-active) at the input. The groups affected by the process are selected in the **Groups to switch** area. If **Energy Save / Activate**, **Manual Fire Alarm Active** or **Disabled** has been selected as the process, the groups selection is disabled because these events always affect the entire system.




Figure 92: Configuring the IO box input

Operating mode	Function
Switch Maintained Luminaires	Switches maintained emergency luminaires on/off
Switch Non-Maintained Luminaires	Switches non-maintained emergency luminaires on/off
Start function test	Starts a function test
Block luminaires	Puts emergency luminaires into remote inhibiting mode
Energy Save / Activate	Switches all switchable emergency luminaires off / switches all maintained emergency luminaires on
Manual Fire Alarm Active	Switches all switchable emergency luminaires on
Emergency mode 1h	Switches selected groups into emergency mode for 1 hour (not available in all regions)
Disabled	Disables this input

Table 31: Operating modes of IO box inputs

5.18 Menus

The menu bar is located under the title bar of the WirelessProfessional software window. **The menu bar is not displayed in full-screen mode!** You can use the Alt + Enter key combination to switch between full-screen mode and the normal viewing mode.

WirelessProfessional

Installation and Software Operation

Page 84

5.18.1 File Menu

Figure 93 shows a screenshot with the **File** menu expanded. Table 32 explains the entries in the **File** menu. The **Inspection Log**, **Communications Log** and **System Log** menu functions correspond to those in the **Alarm List** view.




Figure 93: File Menu

Menu entry	Function
Inspection Log	Opens the test run process. See Section 0 A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3). Test run progress
Operationtime Log	Not implemented
Communications Log	Opens the communications log. See Section 5.7.2 Communications log
System Log	Opens the system log. See Section 5.7.3 System log
Quit Application	Closes the WirelessProfessional software

Table 32: File Menu

5.18.2 Options Menu

Figure 94 shows a screenshot with the **Options** menu expanded. Table 33 explains the entries in the **Options** menu.




Figure 94: Options Menu

Menu entry	Function	User level
Serial Port	Manual selection of port for USB coordinator	Anyone
Start Function Test	Starts a function test for all emergency luminaires	Facility manager, installer
Start capacity Test	Starts a duration test for all emergency luminaires	Facility manager, installer
Put Message into Inspection Log	Manual input of messages into test run progress	Anyone
Login / Logout	Login / Logout as facility manager or installer	-
Toggle Fullscreen	Toggles into full-screen mode	Anyone

Table 33: Options Menu

A function or duration test can only be started if the batteries of the emergency luminaires are adequately charged (see Sections 2.2 and 2.3).

WirelessProfessional

Installation and Software Operation

Page 86

5.18.3 Help Menu

Figure 95 shows a screenshot with the **Help** menu expanded. Table 34 explains the entries in the **Help** menu.

Menu entry	Function
Contact	Shows the installer's contact details.
Show Support Information	Shows the device address of the USB coordinator (device number), the date on which the WirelessProfessional software version was created (build date) and the contact details of the installer and distributor (Figure 96)
Activation	Opens the Features view. Additional devices, additional remote facilities and additional timers can be activated here.
Perform Maintenance	Opens the Maintenance view. The Maintenance entry is only enabled if the distributor has activated the maintenance function
Software Update	WirelessProfessional can be updated as of version 2.1. A corresponding update file can be selected and loaded onto the system in the Software Update view.
Toggle Fullscreen	Software is switched to full-screen mode
About....	Shows the software version, build date and manufacturer

Table 34: Help Menu




Figure 95: Help Menu

There are two ways of accessing the Help menu. Firstly, using the top task bar and secondly on the right-hand side using the button in the banner. There is however one difference between them. If you access via the button in the banner, the software can be switched to full-screen mode but this option is not available under Help accessed using the top task bar.



General	
USB-Koordinator address:	1FYA
Device number:	4294967274
Build date:	Monday, July 1, 2019

Installer	
First name:	John
Last name:	Smith
Company:	ABC Utilities Management
Phone:	071 1234567
Email:	smith@abc-utilities.com

Distributor	
Company:	ABC Technik
Contact person:	Max Mustermann
Phone:	030 1234567
Email:	mustermann@abc-technik.de
Order No:	

Save Cancel

Figure 96: Support information window

6 Other Software

WirelessProfessional systems are supplied with other pre-installed software. This is done to deliver various help functions in the WirelessProfessional system. Table 36 provides an overview of the other pre-installed software.

Some of this software is indeed pre-installed on the PC, but you will need to obtain a licence before you can use it.

The VNC Server and Teamviewer Host software allow a WirelessProfessional system to be operated from another computer. The software transfers the screen contents of the WirelessProfessional PC to another computer where the system is operated. The corresponding client software must be installed on this computer for the remote desktop connection (see Table 35).

Software	Function	Licence
VNC Server	Remote desktop software for connections in the local network. Download the client (VNC viewer) from https://www.realvnc.com/download/	Server: Licence needed, www.realvnc.com Client: no licence needed
Teamviewer Host	Remote desktop software for connections via the Internet. Download the client (Teamviewer All-in-one) from http://www.teamviewer.com/de/download/index.aspx	Server(host): no licence needed Client: Licence needed, https://www.teamviewer.com/de/licensing/index.aspx
Cobian Backup	Backup software. Periodically saves the test run progress, communications log and system log.	No licence needed
TigerVNC Server	TigerVNC Server launches desktop VNC (Virtual Network Computing). It runs Xvnc with the corresponding options and launches a window manager on the VNC desktop.	No licence needed
TigerVNC Viewer	TigerVNC Viewer is a viewer (client) for Virtual Networking Computing. Remote desktop software for connections in the local network.	No licence needed

Table 35: Other pre-installed software

7 Networking Systems

The following section describes how the TigerVNC Server is configured.

Note: If there is no TigerVNC Server installed, first install one.
The TigerVNC Server can be found in the WirelessProfessional software package.

1. Launch “Configure VNC Server” from the Start menu




Figure 97: Windows - quick-start menu

2. **Configure** can be used to assign a connection password.




Figure 98: TigerVNC Server settings

WirelessProfessional

Installation and Software Operation

Page 90

3. Change the port to 5901 under “Accept connections on port”.




Figure 99: TigerVNC Server connections

4. Confirm with **OK**.
5. Launch “Run VNC Server” from the Start menu. This link must be saved in the start-up so that the TigerVNC Server is launched automatically with Windows.

Windows 10

- Press the “Windows key + R” key combination
- Enter the command “shell:startup” and then click on “OK”
- Your system’s start-up folder is now automatically called up via Windows Explorer.
- To add a new program to the start-up, click on the Windows symbol in the bottom left in the task bar and search for the desired program in the list. Then simply drag&drop the entry into the start-up folder.
- Windows will now automatically produce a link to the program you have selected. The next time the system is launched, this program will load automatically.




Figure 100: Windows - quick-start menu

6. There is a new symbol for the TigerVNC in the task bar and this shows that the server is running.

7.1.1 IP Address

For the Wireless Professional software to be able to monitor another device via Ethernet, there must be a network connection between the devices.

Admin rights are needed in the device to set up the network adapter properties. If you do not have these rights, please contact your administrator or distributor.

If the monitoring device is not in the same IP address space as the device requiring monitoring, an appropriate route must be created from one IP address space via a gate to the other address space.

The network route is set up in the operating system. Contact your administrator.

A device requiring monitoring can be addressed by the Wireless Professional software both using the DNS and the IP address. For the device to be addressed via DNS, the name server must be entered during network configuration.

The DNS is set up in the operating system. Contact your administrator.

8 Problem-Solving

8.1 During the Installation, a Device Address is Not Shown in the Unknown Nodes Area

Check the following in the order stated:

1. Check that the device is connected to the mains voltage (emergency luminaires: Is the charge check indicator lit up? IO box: Is the green indicator lit up?)
2. If the device is connected to the mains voltage: Go to 2
3. If the device is not connected to the mains voltage: Connect the device to the mains voltage.
4. Check whether the device is transmitting a radio signal. Run the USB coordinator with the PC and WirelessProfessional software next to the device. Check whether the device address is displayed in the **Network Information** view.
5. If the device address is displayed in the **Network Information**: Go to 3.
6. If the device address is not displayed in the **Network Information**: Contact our distributor.
7. Check whether the device address is listed under **Unknown nodes** when you run the USB coordinator with the PC and WirelessProfessional software next to the device.
8. If the device address is listed under **Unknown nodes**: the radio connection to this device is presumably interrupted because the distance between the devices is too great at one or more points in the radio network.
9. If the device address is not listed under **Unknown nodes**, the device has not been correctly registered in this system. To correct this, manually create the luminaire and assign it to the system. Then delete the luminaire again from the system and also from the list of **Unknown nodes**. The luminaire should now automatically appear under **Unknown nodes**.

8.2 Invalid Devices are Displayed in the Unknown Nodes Area

The WirelessProfessional software reports invalid devices if the device firmware is not saved in the WirelessProfessional software. This typically happens when new devices produced at a later date are added to an existing WirelessProfessional system. To update the WirelessProfessional software, contact our distributor.

8.3 After the WirelessProfessional Software is Launched, System Remains in Status is being updated Operating Status

The time for which the automatic test system remains in the **Starting system** operating status (colour symbol 🟡) after a reboot is set by the longer of the two **Time to connection error** and **Time to connection error for IO boxes** times. The **Time to connection error** and **Time to connection error for IO boxes** values can be set in the System view (see Section 5.11.4).

8.4 Forgotten Facility Manager Password

The facility manager password can be reset to **1111** by the installer or our distributor. The facility manager password is reset in the **Installation/System** view.

8.5 Forgotten Installer Password

The installer password can be reset to **2222** by our distributor.

8.6 Luminaire Not Sending Connection Requests / Not Appearing in Unknown Nodes Area

Devices which are not automatically detected by the system can be manually added by the user (see Figure 60 onwards).

8.7 Changing USB Coordinator

1. Disconnect USB coordinator from PC by removing USB coordinator from USB cable.
2. In the software, go to **Installation** → **System** and press the **Reconnect All Devices** button (see Figure 76).
3. Close the software. In the top left of the software under **File**, go to **Quit Application** and confirm the following message with **OK** (The USB cache is deleted).
4. Relaunch the software.
5. Connect the new USB coordinator with the PC.
6. Then establish a connection in the software by selecting the serial port (see Section 3.3).



Warning: Additionally obtained activations for additional luminaires, remote facilities or timers are linked to the ID of the coordinator and are lost if the coordinator is changed. In such cases, please contact your distributor to re-establish the activations. When updating to Wireless Professional 2.3., activations in place are linked to the associated coordinator.

Note: Once the connection to the coordinator has been established, the Wireless Professional software will automatically undertake re-association of all devices by individually disassociating the devices in turn and then re-associating them.

9 Technical Data

Table 36: Technical data*

Operating frequency		865MHz – 868.6MHz
Tuning range		868MHz +/- 100kHz
Type of modulation		GFSK
Name of transmission		F2DCT (1% duty cycle)
HF channel division		868MHz +/- 50kHz
Transmission bandwidth		300kHz
Transmission	power	10dBm (10mW) -10dBm (0.1mW)
maximum effective		
Indoor range		Min. 30m (for luminaires with plastic casing, repeaters and IO boxes) Min. 24m (for luminaires with metal casing)

*For relevant standards and specifications, refer to declaration of conformity

10 Glossary

Automatic test system (ATS)

Automated test system, which may be triggered by hand, comprising parts (such as internal clock, current detectors, light detectors, selector switches) which are connected together to form a system. This system can perform the routine requirements of tests on emergency luminaires and display the test results (EN 62034:2012)

Autonomy time

In the WirelessProfessional software, the term used for the **rated operating period**.

Battery mode

Status of an emergency luminaire with individual battery, which ensures lighting by supplying power from its in-built current source should the general power supply fail (EN 60598-2-22:1998 + A1:2003)

Rated operating period

Period stated by the manufacturer [of emergency luminaires] for which the rated light current is output (EN 60598-2-22:1998 + A1:2003). Known in the WirelessProfessional software as "autonomy time".

Rated light current of the emergency luminaire

The light current, which according to the manufacturer is output within 60 s (0.5 s for workplaces subject to particular hazards) after a fault to the general power supply and is output from then until the end of the rated operating period (EN 60598-2-22:1998 + A1:2003)

Fire alarm input

Option for configuring the inputs of an IO box. If the signal at a fire alarm input is enabled, all switchable emergency luminaires are switched on. If the fire alarm signal is switched off, the emergency luminaires remain switched on for the duration of the fire alarm overrun time and only then are they switched off again.

Fire alarm overrun time

Time during which the emergency luminaires remain switched on once the signal at the fire alarm input is no longer enabled.

Capacity test

Test for whether the battery of the safety lighting system is supplying the system in line with the limit values for the rated duration of emergency mode (EN 62034:2012)

Remote inhibiting mode

Status of an emergency luminaire with individual battery which is taken out of operation by a remote control unit when the general power supply is present and the luminaire does not switch to battery mode when the general power supply fails. (EN 60598-2-22:1998 + A1:2003) Remote inhibiting mode is only permitted during idle times in operation. Only switchable emergency luminaires can be run in remote inhibiting mode. If the emergency luminaire loses radio contact with the automatic test system, remote inhibiting mode is ended after 15 minutes. Emergency luminaires in remote inhibiting operation cannot be tested and remain in remote inhibiting mode even in the event of a fire alarm.

Function test

Test to establish that the circuit is intact and that a lamp, changeover device and energy source are running as intended (EN 62034:2012)

Masking

A function of the WirelessProfessional software, which suppresses error messages from masked devices. Masked devices can be recognised as such in the Configuring Groups view.

Mains operation

Status of an emergency luminaire with individual battery which is operational in emergency mode when the general power supply is present. In the event of a fault with the general power supply, the emergency luminaire with individual battery automatically switches into battery mode (EN 60598-2-22:1998 + A1:2003)

Emergency lighting

Lighting which takes effect when the power supply to the general-purpose lighting fails (CIE Publication 17.4, EN 60598-2-22:1998 + A1:2003)

Non-maintained emergency luminaire

Luminaire in which the lamps for emergency lighting are only switched on when the power supply to the general-purpose lighting fails (EN 60598-2-22:1998 + A1:2003)

Maintained emergency luminaire

Luminaire in which the lamps for emergency lighting are always continuously powered when general-purpose lighting or emergency lighting is needed (EN 60598-2-22:1998 + A1:2003)

Emergency luminaire with individual battery

Maintained or non-maintained luminaire for emergency lighting, containing all parts, such as battery, lamp, control unit and test and monitoring equipment, if provided. These parts are located in the luminaire or in its direct vicinity (i.e. within a cable length of 1 m) (EN 60598-2-22:1998 + A1:2003)

Fault to the general power supply

Status in which the general-purpose lighting is no longer able to guarantee the minimum light level over the escape routes and in which emergency lighting is to start up (EN 60598-2-22:1998 + A1:2003)

11 Revision History

WirelessProfessional – Installation and Software Operation		
Date	Software version/Revision	Comments/Important changes compared to the previous version
09.07.2014	1.2.0	Creation
24.09.2015	1.3.0	Update. "Maintenance" and "Other Software" sections added.
13.07.2017	1.4.0	Updates to WirelessProfessional
10.11.2017	1.4.1	Corrections
14.11.2017	1.4.2	Corrections
16.11.2017	1.4.3	Corrections
23.11.2017	1.4.4	Coordinator change added
01.02.2018	1.4.5	Corrections
19.06.2018	1.4.6	Remote facilities added
21.08.2019	1.4.7	WL Version 2.2, font, "Technical Data" section added
16.09.2019	1.4.8	Changes to fire alarm overrun time in Table 8
07.10.2020	1.4.9	Updates for WL version 2.3

12 List of Key Words

580a9e99-30c8-4bcd-90c2-d5ee57fc0448	70
9b2343df-fce5-4a34-b586-4982d0bbeadc	70
Activate	28, 33
Address	8
Alarm list, view	34
Automatic test	22
Automatic test system	94
Battery error	30
Battery mode	94
Block emergency luminaires	33
Capacity test	9, 22, 23, 33, 41, 55, 94
Capacity test, configuration of	55
Change distributor password	70
Change installer password	66
Colour symbols	27
Communications Log	38
Configuring groups, view	48
Connection error	30
Connection lost	30
Device	8
Device details	75
Device types	8
Distributor, view	69
Email, view	45
Emergency lighting	95
Emergency luminaire with individual battery	95
Emergency luminaire, device details	75
Emergency mode	8
Energy save	28
Energy Save	33
Event device error	80
Failure of the power supply	8
Fault to the general power supply	95
Fire alarm	28
Fire alarm input	94
Fire alarm overrun time	33, 94
Full-screen mode	83
Function test	22, 33, 41, 55, 94
Function test, configuration of	55
Groups	40
Illuminant error	30
Installation	10
Installation, view	48
Installer password	12
Installer, contact details	64
Installing devices	13, 51
Installing devices manually	52
Invalid device	30
IO box	8
IO box, device details	78
Mains operation	94
Maintained emergency luminaire	8, 95
Maintenance	71, 84
Map	18
Maps, view	42
Masking	94
Network Information, view	67
Non-maintained emergency luminaire	8, 95
Processor-controlled emergency luminaire	9
Quit Application	82
Rated light current	94
Rated operating period	94
Remote inhibiting mode	28, 41, 94
Repeater	8
Repeater, device details	77
Reset facility manager password	66
Send/receive radius	7
Software Installation	24
Status symbols	27
Support information	84
Switching emergency luminaires	41
Symbols	27
System Log	39
System requirements	24
System, view	64
Tab	1
Test run progress	36
Test, view	55
Time to connection error	65
Timer, view	57
Unknown node	51
USB coordinator	7
View	1
WirelessControl system	7

13 Contact Information



Identification number: 020221

Date of issue: 02.02.2021

This user manual describes software version 2.3

Publisher: RP-Technik GmbH

Hermann-Staudinger-Str. 10-16, 63110 Rodgau

Technical and editorial content subject to change without notice